
marantz[®]





QUICK START GUIDE

Welcome

Thank you for choosing a Marantz amplifier. This guide provides step-by-step instructions for setting up your amplifier.

Before You Begin





These drawings are for illustrative purposes only and may not represent the actual product(s).

Setup

There are five steps to the setup process.



Install batteries in the remote control unit




Install batteries in the remote control unit

2 Connect the speakers to MODEL 30


3 Connect the CD player to MODEL 30

4 Plug the power cord into a power outlet

5 Begin CD playback








FR



Connect the speakers to MODEL 30



Connecting the speaker cables1) Peel off about 3/8 inch (10 mm) of
sheathing from the tip of the speaker
cable, then either twist the core wire
tightly or apply solder to it.2) Turn the speaker terminal
counterclockwise to loosen it.3) Insert the speaker cable's core wire to
all the way into the speaker terminal.4) Turn the speaker terminal clockwise to
tighten it.




Connect the CD player to MODEL 30

CD player AUDIO OUT ۲ B 4100 R MODEL 30



Plug the power cord into a power outlet



FR

ES

Owner's Manual

 Refer to the Online Manual for other functions information and operation procedure details. manuals.marantz.com/Model30/NA/EN/






- For more information, visit www.marantz.com



1 Press the power operation button.

2 Set the input source to "CD".

Play the CD player. 3







₽

0

0

0



0 Ó

www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

mapantz[®] is a registered trademark.

Printed in Japan 5411 11843 10AM © 2020 Sound United. All Rights Reserved.